




LE1358_SHB910XX

| | | Spare part number | Colours available |
|----|-------------------------|--------------------------|--------------------------|
| 1 | Pan rest | SSPA0965 | |
| 2 | Burner assy medium | SSPA0110 | |
| 3 | Glass | Not available | |
| 4 | Sealing tape | Not available | |
| 5 | Spark generator | SSPA0302 | |
| 6 | Thermocouple | SSPA0620 | |
| 7 | Electrode | SSPA0327 | |
| 8 | Fixing kit | SSPA0021 | |
| 9 | Tap 2x | SSPA0425 | |
| 10 | Wire harness and switch | SSPA0334 | |
| 11 | Control knob | <i>Refer to page 3</i> | |

Control knobs



| | | | |
|--------------------------|---|-----------------------------|--------------|
| Spare part number | SSPA0911 | SSPA0916 | SSPA0913 |
| Colours available | Black (.BK) Matt Nickel (.MNK) Chrome (.CR) | Brushed Nickel/Black (.BNK) | Chrome (.CR) |
| Set quantity | 3 | 3 | 3 |