






LE1310\_SOG70XXX\_ELECTRIC\_SPARK

		Spare part number	Spare part number	Colours available
1	Oven/grill tap			
	<i>Production date: &lt; 16-02-07 (2007015002)</i>	SSPA0455		
	<i>Production date: &lt; 13-01-14 (E013R...)</i>	SSPA0456		
	<i>Production date: ≥ 13-01-14 (E013R...)</i>	SSPA0457		
2	Control knob	<i>Refer to page 4</i>		
3	Ignition switch <b>*12V ignition models only</b>	<i>Refer to page 4</i>		
4	Light switch <b>*if fitted</b>	SSPA0591		
5	Oven door seal	SSPA0062		
6	Piezo ignition <b>*if fitted</b>	<i>Refer to page 4</i>		
7	Oven door	<i>Refer to page 5</i>		
8	Inner door glass	SSPA0253		
9	Oven shelf	SSPA0982		
10	Grill pan (full assembly including trivet and handle)	SSPA0993		
11	Oven burner			
	<i>Production date: &lt; 31-07-21 (E212Y...)</i>	SSPA0191		
	<i>Production date: ≥ 01-08-21 (E213Y...)</i>	SSPA0198		
12	Oven spark electrode	SSPA0626 ≥ 06-12-16 (E340T.....)	SSPA0606 < 06-12-16 (E340T...)	
13	Oven thermocouple			
14	Grill spark electrode	SSPA0627 ≥ 06-12-16 (E340T.....)	Modification kit	
15	Grill thermocouple			
16	Grill door shut-off switch <b>*if fitted</b>	SSPA0605		
17	Grill burner			
	<i>Production date: &lt; 26-10-15 (E299S...)</i>	No longer available		
	<i>Production date: ≥ 26-10-15 (E299S...)</i>	SSPA0185		
18	Spark generator	<i>Refer to page 5</i>		
19	Oven lamp <b>*if fitted</b>	SSPA0560		




**Control knobs**

<b>Control Knob</b>			
<b>Spare part number</b>	SSPA0916	SSPA0911	SSPA0920
<b>Colours available</b>	Brushed-Nickel/Black (.BNK)	Black (.BK) Matt Nickel (.MNK)	Black (.BK)
<b>Set quantity</b>	3,0	3,0	3,0




**Control knobs**

<b>Control Knob</b>		
<b>Spare part number</b>	SSPA0934	SSPA0938
<b>Colours available</b>	Satin (.SA)	Black (.BK) Matt Nickel (.MNK)
<b>Set quantity</b>	2	1

**Ignition switches**

			
<b>Description</b>	Ignition switch round	Ignition switch rectangular	Piezo ignition
<b>Spare part number</b>	SSPA0380	SSPA0381	SSPA0382


## Spark generator




<b>Description</b>	4 terminals, 2 blanks	6 terminals	6 terminals
<b>Spare part number</b>	SSPA0303	SSPA0399	SSPA0301

## Cladding styles


No cladding











Side cladding



Behind handle cladding



## Oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3435.BKX	Clear	Black	No	N/A		Black
SMAO3435.BK1X	Clear	Black	No	N/A		Steel
SMAO3435.BK5X	Clear	Black	Brushed stainless	Sides		Steel
SMAO3435.BK11X	Clear	Black	Linen stainless	Sides		Steel
SMAO3435.BK13X	Clear	Black	Brushed stainless	Sides		Black
SMAO3435.MIR1X	Mirror	Black	No	N/A		Steel
SMAO3435.MIR6X	Mirror	Black	No	N/A		Chrome
SMAO3435.SSX	Sparkling stainless	Black	No	N/A		Black