

INSTRUCTION MANUAL

ITEM NO.:DEVIL BBQ

CE 0063/18

BRUNER
OUTDOOR IN MOTION

Add: Via Buozzi 8 - Buozzistraße 8
I - 39100 Bolzano/Bozen Italy
Tel: +39 0471 542900

Important:

Important: Read these instructions for use carefully so as to familiarize yourself with the appliance before connecting it to its gas container.
Keep these instructions for future reference, if you pass the product on pass the instructions on with it.

1. Model Description-Portable Gas Stove, Portable Gas BBQ
2. This appliance shall only be used with the MSF-1A butane cartridge.
3. Fuel consumption - 150g/hour.
4. Nominal heat input: 1.9 kW.
6. Gas Type: Butane
7. Gas Category: Vapour pressure-butane

Operation:

1. Once removed from all of the packaging ensure that you remove the grill plate and fit it into the correct position which it is packed. (fig 1)
2. At first please open the gas can cover and Please shake the swing rod up before the gas tank is stuck. (fig 2)
3. Visually inspect the canister before you fit it to your cooker, ensure that the nozzle is in good condition and not damaged.
4. If the canister is damaged in any way, do not attempt to fit it onto your stove.
5. Place the canister into the holder and locate the nozzle into the regulator. (fig 3)
6. Now make sure that the cut out on the canisters collar locates with the valve guide. (fig 4)
7. Make sure the flame control knob is into the OFF position first. Once you have your canister in place, slide the locking lever into the LOCK position. (fig 5)
8. At First Shut the gas can cover, then you can now ignite you're the burner by turning the flame control knob anti clockwise until you hear a lick. (fig 6)
9. The clicking sound is the ignition, your burner should now ignite.
10. You can now regulate your flame by turning the flame control knob clockwise to make the flame smaller or anti clockwise to make the flame bigger.
11. Turning the control knob clockwise into the OFF position will turn the unit off completely.
12. To remove the canister simply turn off the cooker, slide the locking lever into the unlock position lift the canister compartment cover and remove the canister.



Fig 1




Fig 2



Fig 3




Fig 4



Fig 5



Fig 6